Northside Coffee Roasters
Morpeth, Northumberland
Hello@northsidecoffee.co

Installation Requirements: *What you need before delivery to your site*

Water:

15mm feed to 15mm compression stop tap within 1 meter of machine.



Waste:

40mm waste with ‘P’ or ‘U’ shaped fitting immediately below the machine.



Power:

Different machines will require different power so ask us to make sure.

*Connection to power must be done by an electrician for your business insurance and machine warranty purposes.



Standard 13amp socket for grinder





